

Enter Your SiriusXM Account Credentials

1. Select **Settings** and then select **SiriusXM Account**.
2. Select **Username** and enter the SiriusXM username and select **OK**.
3. Select **Password** and enter the SiriusXM password and select **OK**.
4. Select **Sign In** to sign into your SiriusXM account.

