
## Step 2: Enter Your SiriusXM for Business Streaming Account Information

The SXBR2 Business Internet Radio requires your SiriusXM for Business streaming username and password to connect to SiriusXM Music for Business. If are not yet subscribed to SiriusXM Music for Business, go to <a href="mailto:siriusxm.com/business">siriusxm.com/business</a> or call **1-866-345-7474**. When subscribed, you will be provided with your account username and password.

1. If you have not previously entered your username and password, or have manually configured the wireless network in the previous step, the Business Internet Radio will already be prompting to enter your username and password. Continue with the next step.

Otherwise, press the **Home** button, turn the **Scroll knob** to highlight Setup and press the **Scroll knob** to select. Turn the **Scroll knob** to highlight **SiriusXM Account** and press **Scroll knob** to select.

- 2. Username will be highlighted. Press the **Scroll knob**. Enter each character in your SiriusXM for Business streaming username and press the **Scroll knob** to select the character. When complete press the **SHIFT** button. Your username is case sensitive.
- **3.** Turn the **Scroll knob** to highlight Password and press the **Scroll knob** to select. Enter each character in your password and press the **Scroll knob** to select the character. When complete press the **SHIFT** button. Your password is case sensitive.





- **5.** Next you will be prompted to select your time zone. Turn the **Scroll knob** to highlight your time zone and press the **Scroll knob** to select.
- **6.** If you are prompted that an Internet Update is available, allow the update to install. Turn the **Scroll knob** to highlight Install Update and press the **Scroll knob** to select. Wait until the update has completed and you see the message, "Please press the Power button".
- 7. The installation is complete. Press the power button if the Business Internet Radio is in Standby mode. The Home screen will be shown. Scroll the **Scroll knob** until the Category icon is highlighted and press the **Scroll knob**. Turn the **Scroll knob** to highlight a category and press the **Scroll knob** to display a list of channels. Turn the **Scroll knob** to highlight a channel and press the **Scroll knob** to tune the channel.

