
Firmware Update

SiriusXM may occasionally update the software for the Sound Station and it is recommended that you always update the software when new software becomes available. The Sound Station will automatically check for software updates when you turn it on, but you also can manually check for any available software updates. Check siriusxm.com for any updated documentation associated with a software update.

1. Press the **HOME** button and turn the **TUNE knob** to highlight Setup. Press the **TUNE knob** to select.
2. Turn the **TUNE knob** to highlight Firmware Update and press the **TUNE knob** to select.
3. If the Sound Station has already detected that a software update is available, it will show a software update available.

If not, the Sound Station will check for a software update. If no update is available, the Sound Station will display “No new updates”.
4. If a software update is available, turn the **TUNE knob** to highlight Install update and press the **TUNE knob** to select.
5. The software update will be applied to the Sound Station. ***Do not turn the Sound Station off during the update, or disconnect the Sound Station power.*** When complete, the Sound Station will restart to complete the update, and display “Please press the POWER button”.

Info

The Info option displays information about the Sound Station serial number and software version.

1. Press the **HOME** button and turn the **TUNE knob** to highlight Setup. Press the **TUNE knob** to select.
2. Turn the **TUNE knob** to highlight Info and press the **TUNE knob** to select. The information will be displayed.

Factory Reset

The Factory Reset option restores the Sound Station to the factory settings. It will erase all the stored network settings, SiriusXM streaming username and password, favorite channels, favorite shows and channels, alarm clock settings, and set all other options back to the factory settings.

1. Press the **HOME** button and turn the **TUNE knob** to highlight Setup. Press the **TUNE knob** to select.
2. Turn the **TUNE knob** to highlight Factory reset and press the **TUNE knob** to select.
3. Confirm that you really want to proceed with the factory reset. Confirm factory reset will be highlighted. Press the **TUNE knob** to proceed with the factory reset, or press the **BACK** button to abort the factory reset.
4. The screen will display “Restoring factory defaults”, restart the Sound Station when complete and display “Please press the POWER button”.

Note that you will have to connect the Sound Station to a network (“Step 1: Connect to a Wireless Network” on page 10), and also enter your SiriusXM username and password (“Step 2: Enter Your SiriusXM Streaming Account Information” on page 13) after performing a Factory Reset.